


Please read this instruction sheet carefully and keep it for future reference. The fitting must be installed by a licensed electrician.

INSTALLATION

Before installation, ensure power is off, and please pay attention to the following steps:

- 1. Hammer the plastic anchors (1) to the ceiling and use the machine screw (2) to fix the mounting plate (3) to the ceiling.
- 2. Connect the mains supply to the terminal block (4), using the following colour code for the wiring:
 - Connect the brown wire to the corresponding terminal on the terminal block Marked "L"
 - Connect the blue wire to the corresponding terminal on the terminal block market "N"
- 3. Fix the canopy of the fitting (9) to the mounting plate (3), with the screws (6) to secure.
- 4. Use the socket ring (7) to secure the glass (8) to the lampholder of the fitting (9)
- 5. Install the bulb onto the lampholder, the bulb must not exceed the specified wattage on the label.
- 6. Restore mains supply and switch on.




Please read this instruction sheet carefully and keep it for future reference. The fitting must be installed by a licensed electrician.

INSTALLATION

Before installation, ensure power is off, and please pay attention to the following steps:

- 1. Thread the centre pipe (1) through the main cable (2) to the nipple on the fitting (3) until tight.
- 2. Weave the suspension chain (4) through the main cable (2) and attach the chain to the nipple on the pipe (1). Then thread the tube (5) to the suspension chain (4) through the canopy (6) and main cable (2) until tight. Lead the main wire (2) through the wire buckle (15)
- 3. Hammer the plastic anchor (7) to the ceiling. And then secure the mounting plate (9) to the ceiling using the machine screws (8)
- 4. Hang the loop (10) of the fitting (3) onto the hook of the mounting plate (9)
- 5. Connect the mains supply to the terminal block (11), using the following colour code for the wiring:
 - Connect the brown wire to the corresponding terminal on the terminal block marked "L"
 - Connect the blue wire to the corresponding terminal on the terminal block marked
 "N"
- 6. Fix the canopy (6) to the ceiling, with screws (12) to secure.
- 7. Use the socket ring (13) to secure the glass (14) to the fitting (3)
- 8. Install the bulb onto the lampholder, the bulb must not exceed the specified wattage on the label.
- 9. Restore mains supply and switch on.



Please read this instruction sheet carefully and keep it for future reference. The fitting must be installed by a licensed electrician.


INSTALLATION

Before installation, ensure power is off, and please pay attention to the following steps:

- 1. Weave suspension chain (1) through the main cable (2) and fix the chain to the loop on the fitting (3). Fix the tube (4) to the suspension chain (1) through the canopy (5) and main cable (2) until tight. Lead the main cable (2) through the wire buckle (14)
- 2. Hammer the plastic anchors (6) to the ceiling. And then fix the mounting plate (8) to the ceiling until tight using the machine screws (7)
- 3. Hang the loop (9) of the fitting (3) onto the hook of the mounting plate (8)
- 4. Connect the mains supply to the terminal block (10), using the following colour code for the wiring:
 - Connect the brown wire to the corresponding terminal on the terminal block Marked "L"
 - Connect the blue wire to the corresponding terminal on the terminal block market "N"
 - Connect the yellow & green wire to the corresponding terminal on their terminal block

marked " Be sure to connect to ground lead.

- 5. Fix canopy (5) to the ceiling, with screws (11) to secure.
- 6. Use the socket ring (12) to secure the glass (13) to the fitting (3).
- 8. Install the bulb onto the lampholder, the bulb must not exceed the specified wattage on the label.
- 8. Restore mains supply and switch on.



Please read this instruction sheet carefully and keep it for future reference. The fitting must be installed by a licensed electrician.

INSTALLATION

Before installation, ensure power is off, and please pay attention to the following steps:

- 1. Fix the nipple (7) to the coupling on the base (5), with the washer and nut (11) to tighten.
- 2. Hammer the plastic anchor (1) to the ceiling.
- 3. Connect the mains supply to the terminal block (2), using the following colour code for the wiring:
 - Connect the brown wire to the corresponding terminal on the terminal block
 Marked "L"
 - Connect the blue wire to the corresponding terminal on the terminal block market "N"
- 5. Fix the ceiling plate (5) to the ceiling, with machine screws (4) to secure.
- 6. Install the bulb onto the lampholder, the bulb must not exceed the specified wattage on the label.
- 7. Attach the glass (6) through the nipple (7), with the rubber pad and nut (8) to secure. And then use the bottom finial (10) to fix the bottom cap (9) to the nipple (7) until tight.
- O Doctors mains supply and switch on